

# Disassembly and cleaning instructions



for trial cup handle

SAP/Art No. 75023343/21000618

These disassembly and cleaning instructions are designed to supplement the existing brochure «Instructions for instrument preparation», Lit. No. 1363.

## Key

- 1 Drill holes
- 2 Screw
- 3 Spiral spring
- 4 Plate with pegs



## Disassembly

In accordance with the instructions for instrument preparation  
Lit. No. 1363

The following applies in addition to or in place of the instructions:

- Unscrew the screw (2) with the ball head screwdriver
- Remove the spiral thread (3)
- Remove the plate with the pegs (4)

## Pre-cleaning

In accordance with the instructions for instrument preparation  
Lit. No. 1363

The following applies in addition to or in place of the instructions:

- Manually pre-clean all drill holes, passages and threads

## Machine cleaning and disinfection

In accordance with the instructions for instrument preparation  
Lit. No. 1363

The following applies in addition to or in place of the instructions:

- Please take special care to ensure that any cavities can be properly rinsed.

## Drying

In accordance with the instructions for instrument preparation  
Lit. No. 1363

The following applies in addition to or in place of the instructions:

- All drill holes and passages can also be dried with pressurised air.

## Checking and testing

In accordance with the instructions for instrument preparation  
Lit. No. 1363

The following applies in addition to or in place of the instructions:

- Check the thread for signs of damage

## Servicing

In accordance with the instructions for instrument preparation  
Lit. No. 1363

## Assembly

In accordance with the instructions for instrument preparation  
Lit. No. 1363

The following applies in addition to or in place of the instructions:

- Assembly is in the reverse to disassembly.
- The plate with pegs can only be removed in one way, whereby the pegs (4) have to be inserted into the drill holes (1).
- The screw (2) should be screwed in as far as to allow the thread to be aligned with the plate with pegs (4). The thread (2) should not protrude.

## Please note

1 Ball head screw driver 75000647/21000410

