

Disassembly and cleaning instructions




for Curved Reamer Shaft

SAP/Art. No. 75006417/41000026

These disassembly and cleaning instructions are designed to supplement the existing brochure «Instructions for instrument preparation», Lit. No. 03389.

Key

- 1 Bayonet sleeve
- 2 Lid
- 3 Cardan shaft



Disassembly

In accordance with the instructions for instrument preparation Lit. No. 03389

The following applies in addition to or in place of the instructions:

- Open the bayonet lock and push the bayonet sleeve (1) back
- Remove the lid (2)
- Take the cardan shaft (3) out of the guide (4)

Pre-cleaning

In accordance with the instructions for instrument preparation Lit. No. 03389

The following applies in addition to or in place of the instructions:

- Pre-clean the cardan joints and reamer head manually

Machine cleaning and disinfection

In accordance with the instructions for instrument preparation Lit. No. 03389

The following applies in addition to or in place of the instructions:

- Please take special care to ensure that any cavities are properly rinsed

Drying

In accordance with the instructions for instrument preparation Lit. No. 03389

The following applies in addition to or in place of the instructions:

- The cardan shaft and reamer head can also be dried with air pressure

Checking and testing

In accordance with the instructions for instrument preparation Lit. No. 03389

The following applies in addition to or in place of the instructions:

- Check for any damage

Servicing

In accordance with the instructions for instrument preparation Lit. No. 03389

Assembly

In accordance with the instructions for instrument preparation Lit. No. 03389

The following applies in addition to or in place of the instructions:

- Assembly is in reverse to disassembly

